


# SERVICING PRECAUTIONS

## Air Recharging in Compressor


Test the refrigeration by connecting it electrically before refilling operation. It is necessary to ascertain the function of the motor-compressor and identify the defects immediately. If the defects have been found, empty the old system of eventual R-12 residue by breaking off the end of the extension piece at its narrow point. (Figure 1)

Replace the filter and any damaged components. Unsolder and pull off the piece remaining inside the service tube and then attach an extension completely with male Hansen and last, solder it to the same tube again. (Figure 2)



It is necessary to execute the soldering operation with valve open so that the fumes caused by oil residue can come out freely without blowholes between two tubes during heating the point to be soldered.

The extension fitted with the male Hansen is connected to the female fitting of the vacuum pump tube. (Figure 3)




Air evacuating from the system begins so soon as the pump starts. The refrigeration system must be kept under vacuum until the reading on the low-pressure gauge indicates vacuum (0 absolute, -1 atm., -760 mm hg) in any case it is advisable to keep the pump running for about 60 minutes. (Figure 3)


In case that a considerable leakage occurs and to stop the vacuum pump will be necessary and add a small quantity of Freon to the system, if vacuum should not be obtained (pressure gauge can't fall to 1 atmosphere), start the refrigeration unit and find the leakage with the special leak-finder. When the defective soldering point is visible, re-do it after opening the extension tube valve and reestablishing the normal outside pressure inside the group.

Because the melted alloy is sucked into the tubes and block them, the pressure must be rebalanced when vacuum is in the system in soldering. As soon as the

vacuum operation is over, add the quantity in grams of R-12 to the refrigerant system. Remember that every system has an exact quantity of R-12 with a tolerance of  $\pm 5$  grams that can be added. (Figure 4)



Before performing this operation (if the vacuum pump and refilling cylinder are connected), make sure that the valve placed between the vacuum pump and refilling tube are closed to keep the Freon for adding to the system. (Figure 5)




In addition, check the graduated scale on the cylinder for the quantity of R-12 to be added, for example, if we have 750 grams of Freon in the cylinder and must add 165 grams to the group, this amount will be reached when R-12 has dropped to 585 grams, remembering that the indicator shows a lower limit of meniscus. Do this after choosing the scale corresponding to the gas pressure different scales reported as the same gas pressure indicated by the pressure gauge on the top of the column. To make R-12 flow into the system, open the valve placed at the base of the cylinder and connected to the filling tube. The amount of Freon cannot be added to the system all at once because it may cause a blocking of motor-compressor. Therefore, proceed by adding original quantity of about 20-30 grams and close the valve immediately.

The pressure rises and the motor-compressor must start, sucking the gas and making the pressure go down again. Regulate the valve again, maintaining the same manner until reaching to the quantity of R-12 established for the system being charged. When the system is running, the suction pressure must be stabilized between 0.10 to 0.4 atmosphere.


## Air Recharging in Compressor

Test the refrigeration by connecting it electrically before refilling operation. It is necessary to ascertain the function of the motor-compressor and identify the defects immediately. If the defects have been found, empty the old system of eventual R-134a residue by breaking off the end of the extension piece at its narrow point. (Figure 1) Replace the filter and any damaged components. Unsolder and pull off the piece remaining inside the service tube and then attach an extension completely with male Hansen and last, solder it to the same tube again. (Figure 2)



It is necessary to execute the soldering operation with valve open so that the fumes caused by oil residue can come out freely without blowholes between two tubes during heating the point to be soldered.

The extension fitted with the male Hansen is connected to the female fitting of the vacuum pump tube. (Figure 3)




Air evacuating from the system begins so soon as the pump starts. The refrigeration system must be kept under vacuum until the reading on the low-pressure gauge indicates vacuum (0 absolute, -1 atm., -760 mm hg) in any case it is advisable to keep the pump running for about 60 minutes. (Figure 3)


In case that a considerable leakage occurs and to stop the vacuum pump will be necessary and add a small quantity of Freon to the system, if vacuum should not be obtained (pressure gauge can't fall to 1 atmosphere), start the refrigeration unit and find the leakage with the special leak-finder. When the defective soldering point is visible, re-do it after opening the extension tube valve and reestablishing the normal outside pressure inside the group.

Because the melted alloy is sucked into the tubes and block them, the pressure must be rebalanced when vacuum is in the system in soldering. As soon as the

vacuum operation is over, add the quantity in grams of R-134a to the refrigerant system. Remember that every system has an exact quantity of R-134a with a tolerance of  $\pm 5$  grams that can be added. (Figure 4)



Before performing this operation (if the vacuum pump and refilling cylinder are connected), make sure that the valve placed between the vacuum pump and refilling tube are closed to keep the Freon for adding to the system. (Figure 5)



In addition, check the graduated scale on the cylinder for the quantity of R-134a to be added, for example, if we have 750 grams of Freon in the cylinder and must add 165 grams to the group, this amount will be reached when R-134a has dropped to 585 grams, remembering that the indicator shows a lower limit of meniscus. Do this after choosing the scale corresponding to the gas pressure different scales reported as the same gas pressure indicated by the pressure gauge on the top of the column. To make R-134a flow into the system, open the valve placed at the base of the cylinder and connected to the filling tube. The amount of Freon cannot be added to the system all at once because it may cause a blocking of motor-compressor. Therefore, proceed by adding original quantity of about 20-30 grams and close the valve immediately.

The pressure rises and the motor-compressor must start, sucking the gas and making the pressure go down again. Regulate the valve again, maintaining the same manner until reaching to the quantity of R-134a established for the system being charged. When the system is running, the suction pressure must be stabilized between 0.10 to 0.4 atmosphere.

# 1. SPECIFICATIONS

## 1-1 GR-242M / MV / S / SV

ITEMS		SPECIFICATIONS	ITEMS		SPECIFICATIONS
NET CAPACITY (ℓ/)	FREEZER	60 ℓ	SHELF	FREEZER	1 EA
	REFRIGERATOR	140 ℓ		REFRIGERATOR	2 EA
	TOTAL	200 ℓ	VEGETABLE TRAY		1 EA
DIMENSIONS (mm)		540(W)×607(D)×1407(H)	EGG TRAY		1 EA
NET WEIGHT (kg)		46	ICE TRAY		1 Pieces(PLASTIC)
COOLING SYSTEM		Fan Cooling	ICE BANK		1 Piece
TEMPERATURE CONTROL		Knob Dial	COMPRESSOR		P.T.C Starting Type
DEFROSTING		Full Automatic	EVAPORATOR		Fin Tube Type
		Heater Defrost	CONDENSER		Pipe on Sheet Type
		With a Timer	REFRIGERANT		R-12 (140g)
OUT CASE		Coated Steel Sheet	LUBRICATING OIL		HTS-95 (210cc)
INNER CASE		A B S			
INSULATION		Polyurethane Foam			

## 1-2 GR-282M / MV / S / SV

ITEMS		SPECIFICATIONS	ITEMS		SPECIFICATIONS
NET CAPACITY (ℓ/)	FREEZER	60 ℓ	SHELF	FREEZER	1 EA
	REFRIGERATOR	170 ℓ		REFRIGERATOR	3 EA
	TOTAL	230 ℓ	VEGETABLE TRAY		1 EA
DIMENSIONS (mm)		540(W)×607(D)×1553(H)	EGG TRAY		1 EA
NET WEIGHT (kg)		48	ICE TRAY		1 Pieces(PLASTIC)
COOLING SYSTEM		Fan Cooling	ICE BANK		1 Piece
TEMPERATURE CONTROL		Knob Dial	COMPRESSOR		P.T.C Starting Type
DEFROSTING		Full Automatic	EVAPORATOR		Fin Tube Type
		Heater Defrost	CONDENSER		Pipe on Sheet Type
		With a Timer	REFRIGERANT		R-12 (140g)
OUT CASE		Coated Steel Sheet	LUBRICATING OIL		HTS-95 (210cc)
INNER CASE		A B S			
INSULATION		Polyurethane Foam			

### 1-3 GR-242MF / MVF / SF / SVF


ITEMS		SPECIFICATIONS	ITEMS		SPECIFICATIONS
NET CAPACITY (ℓ/)	FREEZER	60 ℓ	SHELF	FREEZER	1 EA
	REFRIGERATOR	140 ℓ		REFRIGERATOR	2 EA
	TOTAL	200 ℓ	VEGETABLE TRAY		1 EA
DIMENSIONS (mm)		540(W)×607(D)×1407(H)	EGG TRAY		1 EA
NET WEIGHT (kg)		46	ICE TRAY		1 Pieces(PLASTIC)
COOLING SYSTEM		Fan Cooling	ICE BANK		1 Piece
TEMPERATURE CONTROL		Knob Dial	COMPRESSOR		P.T.C Starting Type
DEFROSTING		Full Automatic	EVAPORATOR		Fin Tube Type
		Heater Defrost	CONDENSER		Pipe on Sheet Type
		With a Timer	REFRIGERANT		R-134a (120g)
OUT CASE		Coated Steel Sheet	LUBRICATING OIL		FREOL <del>¥22</del> G (210cc)
INNER CASE		A B S			
INSULATION		Polyurethane Foam			

### 1-4 GR-282MF / MVF / SF / SVF

ITEMS		SPECIFICATIONS	ITEMS		SPECIFICATIONS
NET CAPACITY (ℓ/)	FREEZER	60 ℓ	SHELF	FREEZER	1 EA
	REFRIGERATOR	170 ℓ		REFRIGERATOR	3 EA
	TOTAL	230 ℓ	VEGETABLE TRAY		1 EA
DIMENSIONS (mm)		540(W)×607(D)×1553(H)	EGG TRAY		1 EA
NET WEIGHT (kg)		48	ICE TRAY		1 Pieces(PLASTIC)
COOLING SYSTEM		Fan Cooling	ICE BANK		1 Piece
TEMPERATURE CONTROL		Knob Dial	COMPRESSOR		P.T.C Starting Type
DEFROSTING		Full Automatic	EVAPORATOR		Fin Tube Type
		Heater Defrost	CONDENSER		Pipe on Sheet Type
		With a Timer	REFRIGERANT		R-134a (120g)
OUT CASE		Coated Steel Sheet	LUBRICATING OIL		FREOL <del>¥22</del> G (210cc)
INNER CASE		A B S			
INSULATION		Polyurethane Foam			

## 2. PARTS IDENTIFICATION

---




**NOTE :** This is a basic model. The shape of refrigerator is subject to change.


# 3. DISASSEMBLY

## 3-1 HOW TO REPLACE THE DOOR OPENING TYPE (when converting from the left-opening type to right opening type)


1. Separate the Cap ① and Hinge Upper ②.




2. Separating the Freezer Door ③.




3. Separating the Hinge-C ④ and the Refrigerator Door ⑤.




4. Separating the Hinge Lower ⑥.




5. Move the Position of Adjustable Screw Assembly ⑦.




6. Assemble the Hinge Lower ⑥.




7. Move the Cap ⑧, Bracket ⑨ of the Refrigerator Door.




8. Move the Cap ⑩ and Assemble the Hinge-C ④.




9. Assemble the Door Stopper-F ⑪ for Right Opening Type.




10. Move the Cap ⑫ and Assemble the Freezer Door ③.



11. Move the Pin Position ⑬ of the Hinge Upper.




12. Assemble the Hinge Upper ② and the Cap ①.



### 3-2 LAMP REPLACEMENT

1. Unplug the power cord from the outlet.
2. Remove refrigerator shelves.
3. Remove the lamp by turning it counterclockwise as shown in the figure at right.
4. Assemble in reverse order of disassembly. Replacement bulb must be the same specification as original.



# 4. ADJUSTMENT

## 4-1 COMPRESSOR

### 4-1-1 Role

The compressor inhales low temperature and low pressure gas evaporated from Evaporator of the Refrigerator, and condenses this gas to high temperature and high pressure gas, and then plays delivering role to Condenser.

### 4-1-2 Composition

The Compressor is Composed of Compressor Apparatus compressing gas, Compressor Motor moving Compressor Apparatus and Case protecting Compressor Apparatus and Motor. There are PTC-Starter, and Over Load Protector (OLP) in the Compressor outside. On the other hand, because the Compressor consists of 1/1000mm processing precision components and is sealed after producing without dust or humidity, deal and repair with care.

### 4-1-3 Note to Use

- (1) Be careful not to allow over-voltage and over-current.
- (2) No Strike  
If applying forcible power or strike (dropping or careless dealing), poor operation and noise may occur.
- (3) Use proper electric components appropriate to the Compressor.
- (4) Note to Keep Compressor.  
If Compressor gets wet in the rain and rust in the pin of Hermetic Terminal, poor operation and poor contact may cause.
- (5) Be careful that dust, humidity, and flux due to welding don't inflow in Compressor inside in replacing Compressor. Dust, humidity, and flux due to welding which inflows to Cylinder may cause lock and noise.

## 4-2 PTC-STARTER

### 4-2-1 Composition of PTC-Starter


- (1) PTC (Positive Temperature Coefficient) is no-contact semiconductor starting device which uses ceramic material and the material consists of  $BaTiO_3$ .
- (2) The higher the temperature is, the higher resistance value becomes. These features are used as starting device of Motor.

### 4-2-2 Role of PTC-Starter

- (1) PTC is attached to Hermetic Compressor used for Refrigerator, Show Case and starts Motor.
- (2) Compressor for household refrigerator applies single-phase induction Motor.  
For normal operation of single-phase induction motor, in the starting operation flows in both main coil and sub-coil. After the starting is over, the current is cut off in subcoil. The proper features of PTC play the above all roles. So, PTC is used as a starting device of motor.

### 4-2-3 PTC-Applied Circuit Diagram

#### ● According to Starting Method of Motor



### 4-2-4 Motor Restarting and PTC Cooling

- (1) For restarting after power off during normal Compressor Motor operation, plug the power cord after 5 min. for pressure balance of Refrigerating Cycle and PTC cooling.
- (2) During normal operation of Compressor Motor, PTC elements generate heat continuously. Therefore, if PTC isn't cooled for a while after power off, Motor can't operate again.

### 4-2-5 Relation of PTC-Starter and OLP

- (1) If power off during operation of Compressor and power on before PTC is cooled, (instant shut-off within 2 min. or reconnect a power plug due to misconnecting), PTC isn't cooled and a resistance value grows. As a result, current can't flow to the sub-coil and Motor can't operate and OLP operates by flowing over current in only main-coil.
- (2) While the OLP repeats on and off operation about 3-5 times, PTC is cooled and Compressor Motor performs normal operation.  
If OLP doesn't operate when PTC is not cooled, Compressor Motor is worn away and causes circuit-short and fire. Therefore, use a proper fixed OLP without fail.

### 4-2-6 Note to Use PTC-Starter

- (1) Be careful not to allow over-voltage and over-current.
- (2) No Strike  
Don't apply a forcible power or strike.
- (3) Keep apart from any liquid.  
If liquid such as oil or water inflows into PTC, PTC materials it may break due to insulation breakdown of material itself.
- (4) Don't change PTC at your convenience.  
Don't disassemble PTC and mold. If damaging to outside of PTC-starter, resistance value alters and poor starting of compressor motor may cause.
- (5) Use a properly fixed PTC.



### 4-3 OLP (OVER LOAD PROTECTOR)

#### 4-3-1 Definition of OLP

- (1) OLP (OVER LOAD PROTECTOR) is attached to Hermetic Compressor and protects Motor by cutting off current in Compressor Motor by Bimetal in the OLP in case of over-rising temperature.
- (2) When over-voltage flows to Compressor motor, Bimetal works by heating the heater inside OLP, and OLP protects Motor by cutting off current which flows to Compressor Motor.

#### 4-3-2 Role of OLP

- (1) OLP is attached to Hermetic Compressor used to Refrigerator and Show Case and prevents Motor Coil from being started in the Compressor.
- (2) Do not turn the Adjust Screw of OLP in any way for normal operation of OLP.  
(Composition and connection Diagram of OLP)





Figure 22


## 5. CIRCUIT DIAGRAM



- NOTE :** 1. This is a basic diagram and specifications vary in different localities.  
 2. F.I.R. lamp and capacitor are option parts.

# 6. TROUBLESHOOTING

## 6-1 COMPRESSOR AND ELECTRIC COMPONENTS



## 6-2 PTC AND OLP





Figure 24




Figure 25

## 6-3 DEFROST TIMER









Figure 26

## 6-4 ANOTHER ELECTRIC COMPONENTS

### ▼ Cooling is impossible



### ▼ Cooling ability is poor



## 6-5 SERVICE DIAGNOSIS CHART

COMPLAINT	POINTS TO BE CHECKED	REMEDY
Cooling is impossible.	<ul style="list-style-type: none"> <li>• Is the power cord unplugged from the outlet?</li> <li>• Check if the power S/W is set to OFF.</li> <li>• Check if the fuse of power S/W is shorted.</li> <li>• Measure the voltage of power outlet.</li> </ul>	<ul style="list-style-type: none"> <li>• Plug to the outlet.</li> <li>• Set the switch to ON.</li> <li>• Replace a regular fuse.</li> <li>• If voltage is low, wire newly.</li> </ul>
Cooling ability is poor.	<ul style="list-style-type: none"> <li>• Check if the set is placed close to wall.</li> <li>• Check if the set is placed close to stove, gas cooker and direct rays.</li> <li>• Is the ambient temperature high or the room door closed?</li> <li>• Check if putting in hot foods.</li> <li>• Did you open the door of the set too often or check if the door is closed up?</li> <li>• Check if the Thermostat is set to "WARM"</li> </ul>	<ul style="list-style-type: none"> <li>• Place the set with the space of about 10cm.</li> <li>• Place the set apart from these heat appliances.</li> <li>• Make the ambient temperature below.</li> <li>• Put in foods after they get cold.</li> <li>• Don't open the door too often and close it firmly.</li> <li>• Set the knob to "NORMAL"</li> </ul>
Foods in the Refrigerator are frozen.	<ul style="list-style-type: none"> <li>• Are foods placed in cooling air outlet?</li> <li>• Check if the Thermostat is set to "COLD".</li> <li>• Is the ambient temperature within 5°C?</li> </ul>	<ul style="list-style-type: none"> <li>• Place foods in high temperature section. (Front Part)</li> <li>• Set the knob to "NORMAL"</li> <li>• Set the knob to "WARM"</li> </ul>
Dew or ice forms in the chamber of the set.	<ul style="list-style-type: none"> <li>• Are watery foods kept?</li> <li>• Check if putting in hot foods.</li> <li>• Did you open the door of the set too often or check if the door is closed up.</li> </ul>	<ul style="list-style-type: none"> <li>• Seal up watery foods with wrap.</li> <li>• Put in foods after they get cold.</li> <li>• Don't open the door too often and close it firmly.</li> </ul>
Dew forms in the Out Case.	<ul style="list-style-type: none"> <li>• Check if ambient temperature and humidity are high.</li> <li>• Is the gap in the door packing?</li> </ul>	<ul style="list-style-type: none"> <li>• Wipe dew with a dry cloth. This happening is solved in low temperature and humidity naturally.</li> <li>• Fill up the gap.</li> </ul>
Abnormal noise generates.	<ul style="list-style-type: none"> <li>• Is the set positioned in a firm and even place?</li> <li>• Does any unnecessary objects exist in the back side of the set?</li> <li>• Check if the Drip Tray is omitted.</li> <li>• Check if the cover of mechanical room in below and front side is taken out.</li> </ul>	<ul style="list-style-type: none"> <li>• Adjust the Adjust Screw, and position in the firm place.</li> <li>• Remove the objects.</li> <li>• Place it on an original position.</li> <li>• Place the cover at an original position.</li> </ul>
To close the door is not handy.	<ul style="list-style-type: none"> <li>• Check if the door packing becomes dirty by filth such as juice.</li> <li>• Is the set positioned in a firm and even place?</li> <li>• Are too much foods putted in the set?</li> </ul>	<ul style="list-style-type: none"> <li>• Clean the door packing.</li> <li>• Position in the firm place and adjust the Adjust Screw.</li> <li>• Keep foods from reaching to the door.</li> </ul>
Ice and foods smell unpleasant.	<ul style="list-style-type: none"> <li>• Check if the inside of the set becomes dirty.</li> <li>• Did you keep smelly foods without wrapping?</li> <li>• It smells plastic.</li> </ul>	<ul style="list-style-type: none"> <li>• Clean the inside of the set.</li> <li>• Wrap smelly foods.</li> <li>• The new products smell plastic, but it is removed after 1-2 weeks.</li> </ul>



▼ General Control of Refrigerating Cycle

NO.	ITEMS	CONTENTS AND SPECIFICATIONS	REMARKS
1	WELDING ROD	<p>(1) H 30</p> <ul style="list-style-type: none"> <li>• Chemical Ingredients Ag: 30%, Cu: 27%, Zn: 23%, Cd: 20%</li> <li>• Brazing Temperature: 710~840°C</li> </ul> <p>(2) Bcup-2</p> <ul style="list-style-type: none"> <li>• Chemical Ingredients Cu: About 93%</li> <li>P: 6.8~7.5%</li> <li>The rest: within 0.2%</li> <li>• Brazing Temperature: 735~840°C</li> </ul>	<ul style="list-style-type: none"> <li>• Recommend H34 containing 34% Ag in the Service Center.</li> </ul>
2	FLUX	<ul style="list-style-type: none"> <li>• Ingredients and how to make Borax 30%</li> <li>Borax 35%</li> <li>Fluoridation kalium: 35%</li> <li>Water: 4%</li> <li>Mix the above ingredients and boil until they are transformed into liquid.</li> </ul>	<ul style="list-style-type: none"> <li>• Make amount for only a day. Holding period: 1 day</li> <li>• Close the cover of container to prevent dust putting in the FLUX.</li> <li>• Keep it in a stainless steel container.</li> </ul>
3	DRIER ASM	<p>(1) Assemble the drier immediately after unpacking.</p> <p>(2) Keep the unpacked drier at the temperature of 80~100°C.</p>	<ul style="list-style-type: none"> <li>• Don't keep the drier in a outdoor because humidity damages to it.</li> </ul>
4	VACUUM	<p>(1) When measuring with pirant Vacuum gauge of charging M/C, vacuum degree is within 0.5 Torr.</p> <p>(2) If the vacuum degree of the cycle inside is 10 Torr. below for low pressure and 20 Torr. for high pressure, it says no vacuum leakage state.</p> <p>(3) Vacuum degree of vacuum pump must be 0.05 Torr. below after 5 min.</p> <p>(4) Vacuum degree must be same to the value described item (2) above for more than 20 min.</p>	<ul style="list-style-type: none"> <li>• Apply M/C Vacuum Gauge without fail.</li> <li>• Perform vacuum operation until a proper vacuum degree is built up.</li> <li>• If a proper vacuum degree isn't built up, check the leakage from the Cycle Pipe line part and Quick Coupler Connecting part.</li> </ul>
5	DRY AND AIR NITROGEN GAS	<p>(1) The pressure of dry air must be more than 12~16Kg/cm<sup>2</sup></p> <p>(2) Temperature must be more than -20~ -70°C.</p> <p>(3) Keep the pressure to 12~6Kg/cm<sup>2</sup> also when substituting dry air for Nitrogen Gas.</p>	
6	NIPPLE AND COUPLER	<p>(1) Check if gas leaks with soapy water.</p> <p>(2) Replace Quick Coupler in case of leakage.</p> <p>(3) When using couplers, use applicable them in accordance with Refrigerant.</p>	<ul style="list-style-type: none"> <li>• Check if gas leaks from connecting part of Coupler.</li> </ul>
7	PIPE	<ul style="list-style-type: none"> <li>• Put all Joint Pipe in a clean box and cover tightly with the lid so that dust or humidity is not inserted.</li> </ul>	

## 7-2 GR-282

### \* Option

Reversible Door : 281D, 282H

FIR Lamp : 409C

Deodorizer : 604E

Steel Shelf : 136A, 136C, 136E

Plastic Shelf : 149A, 149B, 149C

Lock : 282J

